

DV DONGLE



Thank you for purchasing the DV Dongle. This product contains the DVSI AMBE codec chip that allows for encoding and decoding audio used by D-Star radios and repeaters. The software is constantly being updated and is, therefore, provided on an internet web site. Use a web browser to download the software file <http://www.opendstar.com/tools/DVTool-dist.zip> and extract the included DVTool folder onto your desktop. Using MS Windows, simply double click on the DVTool.jar file included in the DVTool folder. Using Mac OS, double click on dvtool. Using Linux, double click on dvtool.sh. Depending on your operating system and version, you may need to download drivers from <http://www.ftdichip.com/Drivers/VCP.htm> and the JDK 6 software at <http://java.sun.com/javase/downloads/index.jsp>. See the downloadable installation instructions for details.

Installation and operating instructions are available by downloading <http://www.opendstar.com/tools/DVTool-manual.pdf>. Discussion and support is available via the Yahoo group DVDongle at <http://groups.yahoo.com/group/DVDongle>.

Thank you again and we hope you enjoy the product!